

AD-A129 997


HAZARDOUS CHEMICAL FLUOROMETER DEVELOPMENT(U) JOHNS  
HOPKINS UNIV LAUREL MD APPLIED PHYSICS LAB G S KEYS  
FEB 81 JHU/RPL/EED-81-60 USCG-D-79-81


1/1

UNCLASSIFIED

F/G 7/4

NL





MICROCOPY RESOLUTION TEST CHART  
NATIONAL BUREAU OF STANDARDS-1963-A

Hazardous Chemical Fluorometer  
Development

Gary S. Keys



THE JOHNS HOPKINS UNIVERSITY  
APPLIED PHYSICS LABORATORY  
Johns Hopkins Road, Laurel, Maryland 20810

U.S. Coast Guard Research and Development Center  
Avery Point Groton, Connecticut 06340



JANUARY 1981

Second Year Final Report

Document is available to the U.S. Public  
through the National Information Service  
Springfield, Virginia 22161

PREPARED FOR

U.S. DEPARTMENT OF TRANSPORTATION  
UNITED STATES COAST GUARD

OFFICE OF RESEARCH AND DEVELOPMENT  
WASHINGTON, D.C. 20593

DTIC FILE COPY


88 07 01 001

## NOTICE

This document is disseminated under the sponsorship of the Department of Transportation in the interest of information exchange. The United States Government assumes no liability for its contents or use thereof.

The United States Government does not endorse products or manufacturers. Trade or manufacturers' names appear herein solely because they are considered essential to the object of this report.

The contents of this report reflect the views of the Coast Guard Research and Development Center, which is responsible for the facts and accuracy of data presented. This report does not constitute a standard, specification, or regulation.



SAMUEL F. POWEL, III

Technical Director

U.S. Coast Guard Research and Development Center  
Avery Point, Groton, Connecticut 06340



1. Report No. CG-D-79-81	2. Government Accession No. AD A129947	3. Recipient's Catalog No.	
4. Title and Subtitle Hazardous Chemical Fluorometer Development		5. Report Date February 1981	
		6. Performing Organization Code 88898	
7. Author(s) Gary S. Keys		8. Performing Organization Report No. EED-81-60	
9. Performing Organization Name and Address The Johns Hopkins University Applied Physics Laboratory Johns Hopkins Road Laurel, MD 20810		10. Work Unit No. (TRAIS)	
		11. Contract or Grant No.	
12. Sponsoring Agency Name and Address U.S. Department of Transportation United States Coast Guard Office of Research and Development Washington, D.C. 20593		13. Type of Report and Period Covered Second year final report. Jan. 1980 - Dec. 1980.	
		14. Sponsoring Agency Code CGR&DC 28/81	
15. Supplementary Notes The contract under which this report was submitted was under technical supervision of the Coast Guard Research and Development Center, Groton, CT 06340.			
16. Abstract Technical description of a prototype in-situ towed fluorometer for measuring the fluorescence and absorption intensities of hazardous chemicals that could be spilled in the ocean or inland waterways.			
17. Key Words Fluorometer		18. Distribution Statement Document is available to the U.S. public through the National Technical Information Service, Springfield, VA 22161	
19. Security Classif. (of this report) Unclassified	20. Security Classif. (of this page) Unclassified	21. No. of Pages	22. Price

# METRIC CONVERSION FACTORS

## Approximate Conversions to Metric Measures

Symbol When You Know Multiply By To Find Symbol

### LENGTH

in	inches	* 2.5	centimeters	cm
ft	feet	30	centimeters	cm
yd	yards	0.9	meters	m
mi	miles	1.6	kilometers	km

### AREA

in <sup>2</sup>	square inches	6.5	square centimeters	cm <sup>2</sup>
ft <sup>2</sup>	square feet	0.09	square meters	m <sup>2</sup>
yd <sup>2</sup>	square yards	0.8	square meters	m <sup>2</sup>
mi <sup>2</sup>	square miles	2.6	square kilometers	km <sup>2</sup>
	acres	0.4	hectares	ha

### MASS (WEIGHT)

oz	ounces	28	grams	g
lb	pounds	0.45	kilograms	kg
	short tons (2000 lb)	0.9	tonnes	t


### VOLUME

tsp	teaspoons	5	milliliters	ml
tbsp	tablespoons	15	milliliters	ml
fl oz	fluid ounces	30	milliliters	ml
c	cups	0.24	liters	l
pt	pints	0.47	liters	l
qt	quarts	0.95	liters	l
gal	gallons	3.8	liters	l
ft <sup>3</sup>	cubic feet	0.03	cubic meters	m <sup>3</sup>
yd <sup>3</sup>	cubic yards	0.76	cubic meters	m <sup>3</sup>

### TEMPERATURE (EXACT)

°F	Fahrenheit temperature	5/9 (after subtracting 32)	Celsius temperature	°C
----	------------------------	----------------------------	---------------------	----

\* 1 in = 2.54 (exactly) For other exact conversions and more detailed tables, see NBS Misc. Publ. 286, Units of Weights and Measures. Price \$2.25. SD Catalog No. C.13.10.286



## Approximate Conversions from Metric Measures

Symbol When You Know Multiply By To Find Symbol

### LENGTH

mm	millimeters	0.04	inches	in
cm	centimeters	0.4	inches	in
m	meters	3.3	feet	ft
m	meters	1.1	yards	yd
km	kilometers	0.6	miles	mi

### AREA

cm <sup>2</sup>	square centimeters	0.16	square inches	in <sup>2</sup>
m <sup>2</sup>	square meters	1.2	square yards	yd <sup>2</sup>
km <sup>2</sup>	square kilometers	0.4	square miles	mi <sup>2</sup>
ha	hectares (10,000 m <sup>2</sup> )	2.5	acres	

### MASS (WEIGHT)


g	grams	0.035	ounces	oz
kg	kilograms	2.2	pounds	lb
t	tonnes (1000 kg)	1.1	short tons	

### VOLUME

ml	milliliters	0.03	fluid ounces	fl oz
l	liters	0.125	cups	c
l	liters	2.1	pints	pt
l	liters	1.06	quarts	qt
l	liters	0.26	gallons	gal
m <sup>3</sup>	cubic meters	35	cubic feet	ft <sup>3</sup>
m <sup>3</sup>	cubic meters	1.3	cubic yards	yd <sup>3</sup>

### TEMPERATURE (EXACT)

°C	Celsius temperature	9/5 (then add 32)	Fahrenheit temperature	°F
----	---------------------	-------------------	------------------------	----



## TABLE OF CONTENTS

### Section

1.0	INTRODUCTION	1
2.0	SYSTEM DESCRIPTION	1
3.0	UNDERWATER INSTRUMENTATION PACKAGE	7
3.1	Fluorescence and Absorption Sensors	7
3.1.1	Filters	7
3.1.2	Detectors	10
3.1.3	Light Source	10
3.1.4	Logarithmic Amplifiers	10
3.1.5	Light Source Control	14
3.2	Turbidity Measuring Components.	16
3.2.1	Filters	17
3.2.2	Detectors	17
3.2.3	Light Source	17
3.2.4	Logarithmic Amplifiers	17
3.2.5	Summing Amplifier	17
3.3	pH Measurement	19
3.3.1	Sensor Specifications	19
3.3.2	Circuit Description pH Measuremnet	19
3.4	Temperature Measurement	20
3.4.1	Sensor Specifications	20
3.4.2	Circuit Description	20
3.5	Depth Measurement	21
3.5.1	Sensor Specifications	22
3.5.2	Circuit Description	22
3.6	Data Acquisition	24
3.6.1	Analog to Digital Converter	24
3.6.2	Multiplexer Control Circuitry	24
3.7	Power System	26
3.7.1	Basic Power System	26
3.7.2	Lamp Power Supplies	26
3.7.3	Photomultiplier Tube Power Supply	27
3.7.4	Wet Sensor	27
3.8	Mechanical	27
3.8.1	General	27
3.8.2	Towing Ballasting	28
3.8.3	Pressure Vessel	28
4.0	SHIPBOARD CONTROL UNIT	28
4.1	Controls	29
4.2	Display/External Monitor	30

## TABLE OF CONTENTS - CONT.

<u>Section</u>		
4.3	Circuit Description	30
4.3.1	Demultiplexer	30
4.3.2	Sample/Hold Circuit	32
4.3.3	Digital Display	32
4.4	Operational Procedure	33
5.0	SYSTEM CALIBRATION	33
5.1	Fluorescence and Absorption	33
5.1.1	Standard Samples	34
5.1.2	Calibration Procedure	34
5.1.3	Data	34
5.2	Turbidity	34
5.2.1	Standard Samples	39
5.2.2	Calibration Procedure.	39
5.2.3	Data	41
5.3	pH Probe	41
5.3.1	Standard Samples	41
5.3.2	Data	41
5.4	Temperature	41
5.4.1	Standard Source	41
5.4.2	Data	41
5.5	Depth	46
5.5.1	Standard Source	46
5.5.2	Data	46
6.0	SYSTEM STATUS	46
6.1	Sensitivity Comparisons	46
6.2	Lamp Stability Problem	46
6.3	Conclusions.	47
Appendix A	Drawings - Underwater Instrumentation Package	
Appendix B	Drawings - Shipboard Control Unit	



## LIST OF FIGURES

Figure 1 - Towed Hazardous Chemical Fluorometer System	2
Figure 2 - Block Diagram Towed Body Electronics	4
Figure 3 - Block Diagram Control Unit	6
Figure 4 - Block Diagram Towed Body Optics	8
Figure 5 - Filter Response Fluorescence and Absorption	9
Figure 6 - Photodiode Response Curve	11
Figure 7 - Photomultiplier Tube Response Curve	12
Figure 8 - Lamp Relative Spectral Output	13
Figure 9 - Filter Response Turbidity	18
Figure 10 - Temperature Resistor Calibration Networks	22
Figure 11 - Chemical Samples	35
Figure 12 - Standard $10^{-3}$ Solution Preparation	36
Figure 13 - Curve - Anthracene	37
Figure 14 - Curve - Crude Oil	38
Figure 15 - Sensitivity Comparison	40
Figure 16 - Curve - Turbidity	42
Figure 17 - Calibration Curve - pH	43
Figure 18 - Calibration Curve - Temperature	44
Figure 19 - Calibration Curve - Depth	45

### Acknowledgements

The following people were instrumental in developing the Towed Hazardous Chemical Fluorometer System: B. F. Hochheimer, Optics Design; C. J. Kardian, Mechanical Design; J. Daniels, Electrical Design and Test.

## 1.0 Introduction

The Johns Hopkins University Applied Physics Laboratory (APL) has developed an underwater towed fluorometer system that is used to measure the fluorescence of hazardous chemicals spilled in the ocean and inland waterways. This instrument was developed under a contract with The Coast Guard R & D Center, Groton, Connecticut. The contract encompassed a two year period. The first year was devoted to a laboratory feasibility study to determine if the required measuring sensitivity of a specified list of chemicals could be obtained and propose an instrument that could be used to make these measurements. The results of this laboratory study were published in a first year final report, APL Memorandum EEO-80-4. The building of an operational prototype system constituted the second year work.

The following is a final report covering the second year effort. This report describes the Towed Hazardous Chemical Fluorometer System delivered to the Coast Guard R & D Center.


## 2.0 System Description

The Towed Hazardous Chemical Fluorometer System is designed for underwater measurement of fluorescence and absorption characteristics of chemicals that are excited by ultraviolet light at 253.7 nm and fluoresce in the spectrum between 300 and 400 nm. In addition, the instrument measures turbidity, pH, and temperature of the water as well as the depth of the instrument.

The Towed Hazardous Chemical Fluorometer System consists of an Underwater Instrumentation Package (UIP), a Shipboard Control Unit (SCU), a connecting tow cable, and a connecting electrical cable (Fig. 1). The Underwater Instrumentation Package is designed to be towed through the water to make the measurements and transmit the data to the Shipboard Control Unit.

The interconnecting cable consists of a strength member and an electrical cable for power and signal. The mechanical strength member attaches to a tow point near the center of buoyancy. The instrument has ballast added to the nose and thus acts as its own depressor. The electrical cable contains 3 twisted pairs of conductors: one for power and one each for data up and down links. The electrical cable is terminated in a 7 pin underwater connector which mates to a short pigtail cable from the Underwater Instrumentation Package.

The three sensors that measure temperature, pH, and depth are mounted on the aft bulkhead of the UIP and protrude into a free flooding aft cone. The cone is designed to facilitate flushing of this area while the instrument is being towed. The optics that are used to



TOWED HAZARDOUS CHEMICAL  
FLUOROMETER SYSTEM

FIGURE 1

measure the fluorescence, absorption, and turbidity are located internal to the pressure vessel. A flow tube passes through the center of the instrument. The water is forced in the nose and exits at the rear of the aft cone. Inserted in the flow tubes are helical light baffles to block external light from entering the measuring optics. The suite of sensors is conditioned in the instrument package and then digitized and transmitted to the shipboard control unit.

The specifications for the six measurements performed by the instrument are:

Depth: 0-100 meters,  $\pm .1$  meter

Temperature: 0-30°C,  $\pm .1$ °C.

pH: 0-14 pH,  $\pm .1$  pH

Fluorescence: Sensitivity = .001ppm (maximum)\*

Absorption: Sensitivity = .1 ppm (maximum)\*

Turbidity: Sensitivity = 4.0 Nephelometric Turbidity Units (N.T.U.)

\*NOTE: The sensitivity of the measurement of fluorescence and absorption will vary with the chemical being measured.

Figure 2 is a block diagram of the Underwater Instrumentation Package. This diagram indicates the major components of this unit which includes the fluorescence/absorption measuring components, turbidity measuring components, temperature, pH and depth measuring components, data acquisition system, and the power system.

The fluorescence/absorption measuring components consist of a mercury vapor light source which requires a high voltage power supply for initial start-up and a low voltage power supply for operation. The low voltage power supply is controlled by a lamp control circuit which monitors the lamp intensity with a photodiode and adjusts the power supply voltage to maintain constant intensity of the light source. The detector used for the fluorescence measurement is a photomultiplier tube. The absorption detector is a photodiode. The photomultiplier tube and photodiode signals are conditioned by logarithmic amplifiers which provide high detection gain for small concentration solutions and a large dynamic range for detection of high concentration solutions.

The turbidity measuring components consist of first a fiber optic cable which couples visible light from the mercury vapor lamp to the turbidity measuring optics. The turbidity measurement is then made using two detectors, both photodiodes. The detectors measure the straight



line loss of light and the scattered light. The signals are then conditioned by logarithmic amplifiers and combined in a summing amplifier to provide a turbidity signal.

The temperature, depth, and pH measuring components consist of a sensor and conditioning amplifiers for each measurement. The amplifiers supply the necessary reference voltages and amplify the small signals from the sensors to a level that is compatible with the data acquisition system.

The data acquisition system accepts the analog signals from the sensors and digitizes these signals to a 12 bit accuracy ( $\pm 0.05\%$  of the full scale voltage). The digitized signals are then transmitted serially via the data up link to the Shipboard Control Unit. The sample rate of this system can be pre-set to accommodate the desired response of the sensors.

The power system consists of a regulator that converts a 1.5A constant current to a plus and minus 20 volts which is then further regulated to plus and minus 15 volts and plus 5 volts to power the circuits in the UIP. The voltages for the light source and the photomultiplier tube are derived from DC/DC converters.

The Shipboard Control Unit (Figure 3) contains a data controller, digital to analog converter, digital data display, and the power source for the UIP.

The serial data from the Underwater Instrumentation Package is decoded by the data controller and reformatted into a 12 bit data word for each sensor. The data word is then converted to a DC voltage by the digital to analog converter section for use by external data recorders. The digital data display scales the voltages from the digital to analog converter and displays the sensor information in engineering units.

The control switches, located on the front panel of this unit, provide the capability to change functions in the Underwater Instrumentation Package. These functions are converted by the data controller to a digital data word and transmitted serially by the data down link to the Underwater Instrumentation Package.

The power source for the Underwater Instrumentation Package consists of a regulated voltage supply and a constant current regulator.




FIGURE NO. 3

[illegible]



### 3.0 Underwater Instrumentation Package Technical Description

#### 3.1 Fluorescence and Absorption Sensors (Refer to Figure 4)

Figure 4 is a functional diagram of the optics used to measure fluorescence and absorption intensity. A mercury arc lamp is used as the light source and is filtered to pass only the 253.7 nm line.

The photodiode detector directly across from the lamp, which is also filtered to pass only the 253.7 nm line, is used to measure the loss of light due to the absorption of the chemicals being measured.

The photomultiplier tube (PMT), which is filtered to provide a bandpass of 290 to 400 nm, is used to detect the fluorescence of the chemicals. The PMT location relative to the light source is 90 degrees.

The photodiode is connected by a fiber optic cable to the light source. It is filtered to respond to the 546 nm line and is used as a monitor of the lamp intensity. The detector output is used to adjust the lamp power to provide a constant lamp intensity.

The windows in this optics block are quartz to minimize the attenuation of the 253.7 nm light and to avoid self fluorescence which would occur if Plexiglass windows were used.

##### 3.1.1 Filters (Refer to Figure 5)

The criteria for selection of the lamp and absorption detector filters was to provide a very narrow passband centered at 253.7 nm for excitation of the chemicals and attenuation of the other mercury lines. The peak transmission at 253.7 nm is approximately 17.5%. The passband is from 242 to 263 nm.

The filter requirement for the fluorescence detection was to achieve a measuring bandwidth from 280 nm to 400 nm. In addition, the filter must block the 253.7 nm excitation and the longer wavelength lines of the mercury lamp, in particularly the 463 and 546 nm lines. The bandpass was achieved by using a Schott KG1 high pass filter which has approximately 0% transmission at 280 nm with a peak transmission between 350 and 600 nm and a Corning 7-54 bandpass filter with a passband between 230 nm and 420 nm. This combination then provides a detection bandwidth of approximately 280 nm to 420 nm with good attenuation of the 253.7 nm, 463 and 546 nm lines.




FIGURE NO. 4.

## Turbidity Optics

## FLUORESCENCE OPTICS

[illegible]




Figure 5: Optical Filters Response Curves

### 3.1.2. Detectors

Two different detectors are used for the fluorescence and absorption measurements. The absorption measurement uses a Silicon Detector Corp. UV enhanced photodiode. This diode, which is used in the photovoltaic mode, has a response as shown in Figure 6. The diode is one inch in diameter with two active leads of the diode isolated from the case. This configuration allows the diode to be connected in either polarity and with the return lead connected to the case for minimum noise. The fluorescence measurement uses a photomultiplier tube (PMT). The PMT used is a Hamamatsu 1/2" diameter compact tube with a UV transmitting glass envelope. The PMT has a spectral response (Figure 7) from 185 to 650 nm with a maximum response at 340 nm (S5 cathode). The PMT is operated at its maximum supply voltage of 1000 VDC thus achieving maximum gain.

### 3.1.3 Light Source

The light source is a Pen-Ray Model 11SC-1 low pressure, cold cathode, mercury, gaseous discharge lamp. The lamp generates discrete spectral lines with the strongest being the 253.7 nm line (Figure 8).

The lamp is operated with a DC voltage instead of the normal AC voltage. The nominal current through the lamp is approximately 18 mA. The intensity of the lamp is controlled by a photodiode monitor and a feedback circuit which controls the lamp current. The operation of this lamp with a DC source will reduce the lifetime due to migration of the mercury to one electrode. This migration will cause a change in intensity and also a shift in the spectral output. Reversing the polarity of the DC source periodically reduces this process. The rated lifetime of the lamp using an AC source is 5,000 hrs. To obtain the same lifetime using a DC source, the current should be reduced by 1/2. The intensity control circuit will compensate for variations in intensity due to the DC operation.

This lamp has 90% of its intensity in the 254 nm line with the balance in the 313, 365, 405, 436, and 546 nm lines. Increasing the lamp current beyond the normal AC current of 18 mA will increase the intensity of the visible lines a greater percentage than the UV line.

### 3.1.4 Logarithmic Amplifier (Refer to Drawing 5166-0211)

The amplifiers used for both the absorption photodiode and the fluorescence photomultiplier tube are basically the same except for the input stage. The amplifier configuration as shown in the reference drawing consists of an input stage, a linear fixed gain amplifier, and a log amplifier. The linear amplifier and the log amplifier are included

FIGURE 6:  
SPECTRAL RESPONSIVITY  
SILICON DETECTOR PHOTODIODES




FIGURE 7:

## CATHODE-RADIANT SENSITIVITY

HAMAMATSU PHOTOMULTIPLIER TUBE

(R1413)





FIGURE 8:

RELATIVE SPECTRAL INTENSITY

PEN-RAY LAMP



in the same package, a Burr Brown 4127 logarithmic amplifier. The linear and log amplifier gains are adjusted so a 1.0 decade change in input current will produce a 5V change in the output voltage. This can be referenced to the output of the input stage where a 1 mV to 10 mV change will produce a 0 to 5V change at the output of the log amplifier Pin A or S.

The input stage for the absorption measurement (IN-1) is a current to voltage amplifier where the output of U1 will be equal to the current through the diode multiplied by the feedback resistor R1. The input stage for the fluorescence photomultiplier tube (U3) is a unity gain high impedance buffer. Resistor R39 converts the current from the photomultiplier tube cathode to a voltage which is amplified by U3.

The log amplifiers for both sensors have inputs for applying an external offset voltage to set the output to zero volts, compensating for background signals within the sensors. The network associated with this is connected to pin 9. The trimpots, R12 and R13, are vernier adjustments while the coarse adjustment is obtained by connecting R32 and R33 to the offset network. The required offset voltage for the coarse adjustment potentiometer is obtained from the voltage reference source which consists of Q1, a heater controlled precision 10.24 voltage source, and U5. U5 and the associated gain resistors are used to generate plus and minus reference voltages between zero and 10.0 volts. The calibration inputs can be used to insert external voltages to check the operation of the logarithmic amplifier.

The procedure for initially adjusting the operating range of this circuit is to apply an input current to pin 2 of  $1 \times 10^{-9}$  amps or  $1 \times 10^{-3}$  volts to pin 17. These conditions will produce a 1.0 mV signal at the output of the input stage. This will be the minimum input signal. Adjust R12 and R13 to the zero volt point then tailor R3 and R5 (for Channel 1) or R19 and R21 (for channel 2) for zero volts at the output of the log amplifier pins A or S.

The gain of the amplifier is set by the value of resistor R9 or R25. The values shown should result in an output voltage change of 5.0V for a one decade change in input current or voltage.

### 3.1.5 Light Source Control (Refer to Drawing 5166-0161)

Referring to Figure 2, the components required to control the light source are a photodiode, the lamp control circuitry, a 600V power supply, and a 1500V power supply.



There are three modes of operation for the light source: start up, constant voltage operation, and intensity control operation. The start up mode is used only when the lamp is initially energized. This mode is controlled by a command from the control unit via the data down link. The characteristics of the lamp require that a high voltage be applied to the lamp for initial ionization, approximately 1500VDC. This step is accomplished by energizing both the 1500V supply and the 600V supply. The high voltage ionizes the lamp, and the 600V supply provides the current to sustain the lamp. Once the lamp is on, the high voltage supply can be turned off. A current sensing resistor and a comparator determine when the lamp is fully on. This indication is transmitted to the control unit via the data up link and lights a "LAMP ON" indicator.

The constant volt operation is used during the turn on sequence and can be manually selected from the control unit via the data down link. This mode of operation places a constant voltage on the lamp, initially setting the lamp intensity to a desired operating point. This mode is desired until the lamp reaches a stable condition. The disadvantage of this operation is that the intensity will change due to lamp heating.

The intensity control operation is used for normal operation of the instrument. In this mode, the desired intensity of the lamp is pre-set; and the photodiode, which is filtered to operate using the 546 nm line of the lamp, monitors the intensity of the lamp. The lamp control circuitry will develop error voltages when the intensity changes which requires adjustment of the 600V power supply to return the intensity to the pre-set value.

The circuitry contained in this section consists of the intensity control circuits (U1 thru U5), relay K1, for constant voltage control, relay K1<sub>2</sub> for lamp-start control, and comparator U9 for sensing the lamp current. The input amplifier U1 is a current to voltage amplifier with a bandpass of 1Hz. The output of U1 is fed to a summing resistor R2. A positive reference source derived from a stable reference network R17, R19, R15, U7 and CR3 is fed to summing resistor R3. U2 amplifies the difference. U3 and U4 amplifies this difference signal by a gain of 190. The output of U4 is coupled to a final stage U5 through relay K1 contacts 2 and 15. U5, which has a gain of 2, provides a reference for loop operation and controls the 600V power supply. When operating in the constant voltage mode U5 receives its input from the voltage divider network R28, R32, and R33 through relay contacts 1 and 15. The voltage comparator U9 senses lamp current through a 240  $\Omega$  resistor. Its output goes to a +5V level when the current through the sense resistor produces a voltage that exceeds the reference on U9-3. When K1 is energized, contacts 1 and 15 are connected, placing the system in the constant voltage mode. This causes contacts 14 and 4 to make, placing 5.0 Volts

on the constant voltage indicator line. K1<sub>2</sub> is the high voltage power supply (H.V.P.S.) relay. When energized, contacts 6 and 12 make, turning on the H.V.P.S. Also, 7 and 9 make, energizing K1, forcing the control to constant voltage operation. A +5.0V level on the H.V.P.S. indicator signal line signifies the H.V.P.S. is operating.

The following procedure is used to adjust the lamp control circuitry:

- (1) Select constant voltage mode of operation and connect a meter between R11 (K1 side of resistor) and common.
- (2) Adjust R28 for zero volts at this point.
- (3) Connect a voltmeter to U5-10 and adjust R16 for -1.9V.
- (4) Select the 1200 VDC scale on the meter and connect the meter to the output terminals of the 600V power supply.
- (5) Select the lamp start mode and adjust R28 for 600 VDC.
- (6) Select lamp control mode operation and adjust R15 for 590 VDC.

### 3.2 Turbidity Measuring Components (Refer to Figure 4)

Figure 4 is a functional diagram of the optics used to measure the turbidity of the water. This measurement is made by measuring the direct line loss of light from the light source to a detector and comparing it with the increase in light from a detector located 90° from the light source. The light source is a fiber optic cable that couples light from the stable mercury lamp used for the fluorescence measurement. This is filtered to pass the 546 nm mercury line.

Both the inline and 90° detectors are photodiodes and are filtered to detect the 546 nm signal. The 546 nm line was selected because it was readily available and also is outside the sensing bandwidth of the fluorescence measurements, thereby eliminating interference which could be caused by light coupling between the optical systems. The windows used in these optics are Plexiglass. Plexiglass can be used since the operating wavelength of 546 nm is readily passed by Plexiglass and does not cause interfering fluorescence.

3.2.1 Filters  
(Refer to Figure 9)

The filters used in this measurement are bandpass filters for the two photodiode detectors and a highpass filter for the light source. The bandpass filters are 3-cavity filters centered at  $546 \text{ nm} \pm 2 \text{ nm}$  with a bandwidth of  $12 \pm 2 \text{ nm}$ . The peak transmission is 60%.

A highpass filter, Kodak Wratten #9, was selected for the light source to attenuate the other mercury lines that are all shorter wavelengths. The highpass filter provides more light intensity in the measuring chamber than a bandpass filter.

3.2.2 Detectors  
(Refer to Figure 6)

Both the absorption and scattering detectors are Silicon Dectector Corporation silicon diodes which are enhanced for the blue spectrum. The specifications, except for response, are the same as noted in the Fluorescence and Absorption Sensor Section 3.1.2.

3.2.3 . Light Source

The light source is the Pen Ray lamp used in the Fluorescence and Absorption Optics. (see section 3.1.3). This is coupled to the turbidity chamber by a fiber optic cable. The fiber optic cable, Oriel Corporation part #6451, is 36" long and has a fiber bundle of .125 inches. The transmission spectrum is from 400 nm to 1300 nm. The transmission at the 546 nm wavelength is 50%.

3.2.4 Logarithmic Amplifiers  
(Refer to Drawing 5166-0141)


The configuration of the amplifiers for both the scattering and absorption measurements is the same as the one used for the absorption measurement in the Fluorescence and Absorption Section 3.1.4. The only change is that the input amplifier gains are tailored for the different light intensities.

3.2.5 Summing Amplifier  
(Refer to Drawing 5166-0171)

The turbidity measurement is actually two measurements; the combination of these measurements is used to define turbidity concentrations. A summing circuit is used to combine the two signals.

The amplifier, as shown on the referenced drawing, consists of an operational amplifier configured as a summing amplifier. The two

FIGURE 9:  
OPTICAL FILTERS RESPONSE  
TURBIDITY



signals are applied to two 10.0 K $\Omega$  input resistors. The amplifier output is then a direct sum of these two signals. The gain for each signal is unity. The diode configuration on the output is needed to limit the saturation voltage to approximately 10V to prohibit over-driving the data multiplexer system.

### 3.3 pH Measurement

This measurement is accomplished by using a Broadley-James pH probe mounted externally to the pressure vessel of the Underwater Instrumentation Package and conditioned by circuitry to provide a zero to ten volt signal equal to a pH level of zero to fourteen.

#### 3.3.1 Sensor Specifications

This probe, similar to a Broadley-James Model 9027 probe except in the packaging, is a dual electrode probe with a reference electrode and a measuring electrode integral to a single stem. It is sealed and requires no maintenance other than periodic cleaning. The probe has a pH range from 0 - 14, a temperature range of -5°C to 100°C, and a pressure range to 150 psi.

#### 3.3.2 Circuit Description (Refer to Drawing 5166-0231)

The pH probe generates a small voltage output with a change in pH levels. The input impedance of the conditioning amplifier must be high. The pH probe conditioning circuitry is located on the circuit board 5166-0231. This circuitry provides gain, offset control, and filtering. The pH probe voltage is connected to the isolation amplifier U1. U1 output is coupled to an instrumentation amplifier (contained in U2), amplified, and then fed to a buffer amplifier which incorporates fine gain and output offset adjustments. The final output stage is a 10 Hz low pass filter.

The following procedure is used to adjust the pH conditioning electronics:

- (1) Disconnect J4 (pH Probe).
- (2) Adjust R17 to its mid-position.
- (3) Connect U2-12 and U2-15 to common (U2-28).
- (4) Turn power on.
- (5) With a voltmeter connected between Pin U2-3 and common, adjust R16 for 0 volts  $\pm 0.01V$ .
- (6) Connect U2-2 to common.
- (7) With the meter connected between Pin U2-1 and common, adjust R22 for 0 volts  $\pm 0.01V$ .

- (8) Move the meter lead from U2-1 to U2-7, and adjust R21 for 0 volts  $\pm .01V$ .
- (9) Move the meter lead from U2-7 to U2-20, and adjust R15 for 10 volts  $\pm .01V$ .
- (10) Remove connections from U2-12 and U2-15.
- (11) Reconnect J4 (pH Probe).
- (12) Connect meter from U2-7 to common.
- (13) Immerse pH probe into a 4 pH solution.
- (14) Adjust R22 for +2.857 volts  $\pm .01V$ .
- (15) Change pH solution to 10 pH.
- (16) Adjust R17 for +7.143 volts  $\pm .01V$ .
- (17) Repeat steps 13 thru 16 until required parameters are obtained.

#### PH Probe Calibration Parameters:

<u>PH Level</u>	<u>U1 (Input)</u>	<u>U2-7 Output</u>
4	+ .293V	+3.045V
7	.013V	+5.010V
10	.353V	+7.192V

### 3.4 Temperature Measurement

The temperature measurement is made using a thermistor probe that protrudes through the pressure vessel into the aft free flooding section of the instrument. The temperature range is 0 to 30°C with a  $\pm 0.1^\circ C$  accuracy.

#### 3.4.1 Sensor Specifications

The sensor used is a Yellow Springs Instrument Co. Model 710 stainless steel probe. It has a pipe fitting for threading into the pressure vessel and can withstand 500 psj. The probe has a linear response over a temperature range of  $-30^\circ C$  to  $+100^\circ C$ . The interchangeability of probes is within  $\pm .15^\circ C$ . The time constant of the probe is 3.6 sec.

#### 3.4.2 Circuit Description (Refer to Drawing 5166-0151)

The temperature probe conditioning circuitry is located on the Temp/Depth circuit board 5166-0151 and consists of a thermistor bridge, instrumentation amplifier, buffer amplifier, and active filter.

The thermistor bridge configuration consists of R3-R7 along with two thermistors external to the board. The bridge output (21.393 mV/°C) is amplified by the instrumentation amplifier and its output is coupled to a buffer amplifier which contains the fine gain trim and output offset adjustments. The final stage is a 10 Hz low pass active filter. The overall gain of the circuit is 15.58.


The following procedure is used to adjust the temperature probe conditioning circuitry:

- (1) Disconnect J3 (temperature probe).
- (2) Place Temp/Depth board on a card extender.
- (3) Adjust R9 to its mid-position.
- (4) Connect U1-12 and U1-15 to common (U1-28).
- (5) Turn power on.
- (6) With a voltmeter connected between Pin U1-3 and common, adjust R8 for 0 volts  $\pm .01V$ .
- (7) Connect Pin U1-2 to common.
- (8) Move meter connection from U1-3 to U1-1 and common, adjust R14 for 0 volts  $\pm .01V$ .
- (9) Move meter connection from U1-1 to U1-7 and common, adjust R13 for 0 volts  $\pm .01V$ .
- (10) Move meter lead from U1-7 to U1-20 and common, adjust R1 for 4 volts  $\pm .01V$ .
- (11) Remove connection from U2-12 and U2-15 to common.
- (12) Connect resistor network A as shown in Figure 10.
- (13) Connect meter from U1-7 to common and adjust R4 for 0 volts  $\pm .01V$ .
- (14) Change resistor network to B in Figure 10 and adjust R9 for 8.333 volts.
- (15) Repeat steps 12-14 until required parameters are obtained.
- (16) Reconnect J3.
- (17) Lower temperature of probe to 0°C and adjust R4 for 0 volts  $\pm .01$ .
- (18) Raise temperature of probe to 30°C and adjust R9 for 10 volts  $\pm .01$ .
- (19) Repeat steps 17-19 until required parameters are met.

### 3.5 Depth Measurement

The depth measurement is obtained by using a pressure transducer that is mounted internal to the pressure vessel and vented into the aft free flooding area of the instrument. The measurement range is 0 to 100 meters with a 0.1 meter accuracy.

Figure 10  
Resistor Calibration Networks



### 3.5.1 Sensor Specifications

The pressure transducer is a Sensotec TJE Series transducer with an overall accuracy of  $\pm 0.1\%$  of full scale. The transducer measures absolute pressure with full scale equal to 150 psi. It also has a 50% pressure overrange capability.

The measuring port has a stainless steel diaphragm which connects to a foil strain gauge bridge. The bridge excitation is 10 VDC with an output of 3 mV/V. A pressure of 100 psi produces a 30 mV signal.

### 3.5.2 Circuit Description (Refer to Drawing 5166-0151)

The depth transducer conditioning circuitry is contained on the Temp/Depth board 5166-0151 and consists of an instrumentation amplifier, buffer amplifier, and output filter.



The instrumentation amplifier input voltage range is 2.204 mV to 24.049 mV which corresponds to a depth of 0 to 100 meters respectively. This amplifier has a gain of 457.7. The instrumentation amplifier output is coupled to a buffer amplifier which incorporates a fine gain trim and output offset adjustments.

The final stage is a 10 Hz low pass active filter. The following procedure is used to adjust the depth transducer conditioning circuitry.

- (1) Disconnect J5 (Depth Transducer).
- (2) Place Temp/Depth board on a card extender.
- (3) Adjust R17 to its mid-position.
- (4) Connect U2-12 and U2-15 to common (U2-28).
- (5) Turn power on.
- (6) With meter connected between Pin U2-1 and common, adjust R16 for 0 volts  $\pm .01V$ .
- (7) Connect Pin U2-2 to common.
- (8) With meter connected between Pin U2-1 and common, adjust R22 for 0 volts  $\pm .01V$ .
- (9) Move meter lead from U2-1 to U2-7, and adjust R21 for 0 volts  $\pm .01V$ .
- (10) Move meter lead from U2-7 to U2-20, and adjust R15 for 0 volts  $\pm .01V$ .
- (11) Remove connection from U2-12 and U2-15.
- (12) Turn power off.
- (13) Connect power supply (+) to U2-12 and (-) to U2-15.
- (14) Turn power on.
- (15) Set power supply to 2.204 mV.
- (16) Connect meter from U2-7 to common.
- (17) Adjust R22 for 0 volts  $\pm .01V$ .
- (18) Set power supply output to 24.049 mV.
- (19) Adjust R17 for 10 volts  $\pm .01V$ .
- (20) Repeat steps 15-19 until required parameters are obtained.
- (21) Turn power off.
- (22) Remove power supply from U2-12 and U2-15.
- (23) Reconnect J5.
- (24) Connect a pressure test unit to the transducer.
- (25) Turn power on.
- (26) Set pressure to 1.0 psi.
- (27) Adjust R22 for meter reading of 0  $\pm .01V$ .
- (28) Change pressure from 1.0 psi to 145.67 psi.
- (29) Adjust R17 for a meter reading of 10  $\pm .01V$ .
- (30) Repeat steps 26-29 until required parameters are obtained.

### 3.6 Data Acquisition

The data acquisition subsystem contains a microprocessor controlled analog data multiplexer, 12 bit analog to digital converter, and a digital multiplexer with an asynchronous serial data transmitter. The system is capable of multiplexing 16 channels of data plus 8 status bits and receiving and decoding 8 control bits. It is configured to sample six data channels at a 60 Hz rate. The number of channels and the sampling rate can easily be changed with software modifications.

#### 3.6.1 Analog to Digital Converter (Refer to Drawing 5154-0121)

The analog to digital (A/D) converter consists of two modules: a 16 channel analog multiplexer (U1) and a 12 bit A/D converter (U2). The multiplexer can either be configured to handle 8 channels of differential inputs or 16 channels of single ended inputs. In this system it is configured single ended. The multiplexer will handle bi-polar signals to a maximum of  $\pm 10$  volts. The A/D converter module (U2) is configured to convert the analog signal from the multiplexer over the full range of  $\pm 10V$ , producing a 12 bit digital word. The addressing for the multiplexer and the control for the A/D converter comes from the multiplexer control board. The multiplexer module and A/D converter are a two component system produced by Analog Devices.

#### 3.6.2 Multiplexer Control Circuitry (Refer to Drawing 5154-0141)

The multiplexer control circuitry controls the analog multiplexer and A/D converter. Its function is to obtain the 12 bit data word from the A/D converter, configure it into a serial data word, and transmit it to the control unit. This circuitry is composed of 5 basic components: a microprocessor (U12), interrupt timing and control (U17, U9), status and control bits (U13), Universal Asynchronous Receiver and Transmitter (UART) (U14), and the A/D interface (U16, U5).

The microprocessor is an Intel 8748 that has an 8 bit CPU and PROM contained in one integrated circuit. The control software for the Underwater Instrumentation Package is stored in this PROM. The microprocessor is interrupt driven. Every 17.5 ms an interrupt occurs which causes the processor to sample each sensor and transmit the data via the data up link to the control unit.

The interrupt timing and control circuitry contains a programmable timer (U17) which generates the 17.5 ms interrupt pulse. This is routed through the control circuit (U9) which, in the case of multiple interrupts, determines the order of processing. Two interrupts are used

in this instrument: sampling and data received. The data received occurs when data is sent from the Shipboard Control Unit (SCU) via the data down link.

The status and control bits are handled in U13. The control bits are sent to U13 by the microprocessor as an eight bit word and are stored in U13. The status bits are also connected to U13 and sampled as eight bit words by the microprocessor.

The UART is controlled by the microprocessor. This circuitry takes the parallel data from the microprocessor and converts it to a serial data stream transmitting it through the line driver (U3) to the SCU. This circuit also accepts serial data from the control unit through a line receiver (U4) and converts it to parallel data to be used by the microprocessor.

The A/D interface consists of a digital interface which accepts the 4 most significant bits of the conversion (U16) and supplies the address for the analog multiplexer. The data is transferred to and from U16 by the microprocessor. The remaining eight bits of the data are connected directly to a parallel input of the microprocessor.

The basic operational sequence of this section is as follows: Each sensor is sampled and converted to a 12 bit digital word and stored in the microprocessor memory until all sensors have been sampled. When the sampling is complete, the processor switches to the data transmit mode. In this mode, it transmits the data serially in eight bit bytes to the control unit. In addition to the sensor data words, a sync word and a status word are also transmitted. Table 1 is the a format for the transmission of each block of data every 17.5 ms.

Table 1 - Uplink Data Format

<u>FUNCTION</u>	<u>#8 BIT BYTES</u>
Sync word	2
Sensor 1	2
Sensor 2	2
Sensor 3	2
Sensor 4	2
Sensor 5	2
Sensor 6	2
Status word	1

The data format for each sensor is identical. Bits 0 thru 11 are data, 12 thru 15 zeros. The sync word is all ones. The status word is all data.

### 3.7 Power System

The power supplied to the instrument is a constant current of 1.5A with a minimum voltage required at the instrument of 50 volts DC. The internal regulators in the instrument then derive the required voltages for all the instrumentation.

#### 3.7.1 Basic Power System. (Refer to Drawings 5166-0101 and 5166-0191)

As shown in drawing 5166-0101, a block labeled Regulator No. 3 contains the zener diodes that regulate the constant current from the control unit to plus and minus 20 volts to supply the remaining regulators. The center point of the zener regulator then becomes the 0 volt reference for all circuitry internal to the Underwater Instrumentation Package. This zero point reference is not connected to the housing, thus isolating the unit from sea water. There is no return connection of this point to the control unit. The input to the zeners, approximately 50V, is floating and not referenced to the control unit ground or sea water. This condition is necessary to generate the plus and minus voltage with respect to the center point of the zener regulator.

The main voltages used by the instrumentation are plus and minus 15 volts and plus 5 volts. These voltages are generated by three integrated circuit regulators located on voltage regulator assembly #2 (5166-0191). These are fixed voltage regulators with a current capability of 1.0A.

#### 3.7.2 Lamp Power Supplies (Refer to Drawings 5166-0181 and 5166-0201)

There are two power supplies associated with the lamp power. Both supplies are Venus Scientific DC to DC converters.

The low voltage supply, a Venus F6, produces 600 VDC at 16 mA with an input voltage of 25 to 31 VDC at 630 mA. This supply is controllable with a DC voltage which enables it to be used with the lamp intensity control circuit. This supply receives its input from a regulator (U2) located on the voltage regulator assembly #1 (5166-0181). As shown in drawing 5166-0201, the 600V supply is connected through an isolation diode network of CR1, CR2, CR3 and a 20K  $\Omega$  resistor which sets the lamp operating current.

The second supply for the lamp is a Venus K30 which provides a maximum output of 3,000 volts at .5 mA. The output of this supply is controlled by the DC input. Varying the input from 3V to 15V will vary the output from 600V to maximum. The input for this supply is generated by a variable regulator (U1) on voltage regulator assembly #1.

The two supplies are combined to power the lamp. The circuitry necessary to achieve this is located on the photomultiplier and HV power supply assembly (5166-0201). The negative outputs of the supplies are connected and go to the lamp through a 240  $\Omega$ , lamp current measuring resistor. The positive output of the K30 supply is connected to the lamp through a diode (CR4) and a 6.2 M $\Omega$  resistor. The diode provides isolation from the 600V supply and the resistor is to limit the current.

### 3.7.3 Photo Multiplier Tube Power Supply (Refer to Drawing 5166-0201)

The PMT power supply is a Venus K15 high voltage DC/DC converter with a maximum output of 1500 volts DC at 1.0 mA. The output is adjusted by varying the DC input from 3 to 15 volts, which changes the output from 300 to 1500 volts. This supply is located on the photo multiplier and HV. power supply assembly (5166-0201) and receives its input from a variable voltage regulator (U3) on the voltage regulator assembly 5166-0181.

### 3.7.4 Wet Sensor (Refer to Drawing 5166-0171)

The purpose of the Wet Sensor is to detect moisture in the instrument and send a signal to the control unit. This circuit is located on the auxiliary electronics board (5166-0171) and consists of a voltage comparator with probes connected to the inputs. A decrease in resistance between the probes causes the output of the comparator to change from 0 VDC to +5 VDC.

### 3.8.0 Mechanical (Refer to Drawing 5166-0100)

#### 3.8.1. General

The overall length from nose piece to stabilizing ring is 47.5". The pressure vessel that houses the optics and instrumentation is made of aluminum pipe 8.5" in diameter and 25.0" long. It has removable end caps with "O" ring seals.

The front nose piece, which acts as an inlet for the water, also contains an underwater connector and ballast weights. It is shaped to reduce the drag of the instrument.

The rear cone, which is free flooding, has a flow tube through the center for the outlet of the water forced through the instrument. This area also contains the wet ends of the temperature, pH, and depth

sensors. Water scoops on the side along with vents allow a slow change in the water in this cavity. This causes a slower response for these sensors but will protect them from physical damage and also turbulent flow which could disturb the measurements. An access plate is provided to allow calibration of these sensors and installation of a protective cap on the pH probe.

The instrument has two hydrodynamic depressing fins and one vertical fin surrounded by a stabilizing ring.

The internal configuration consists of a center flow tube with optics blocks for fluorescence, absorption, and turbidity measurements. Helical light baffles are inserted in the flow tubes to prevent ambient light from entering the instrument. The instrumentation is mounted on an assembly around the flow tubes. This assembly is removable intact with the rear pressure vessel end cap.

#### 3.8.2 Towing and Ballasting

The instrument is towed from a single point located 19.75" aft of the tip of the nose piece. A maximum of 45 lbs. of ballast weight can be secured in the nose piece. When all the ballast is in place, the instrument will enter the water nose down. Due to the positioning of gravity and the tow point, the force of the water striking the fins and stabilizing ring will bring the instrument horizontal at a moderate towing speed (4 knots). This feature provides for optimum flow of water through the instrument. In operations involving very low towing speeds (2 knots or less) and shallow depths, the ballast weights may be trimmed to improve tracking response. This would also reduce the overall weight and make handling easier.

#### 3.8.3 Pressure Vessel

The pressure vessel is an aluminum pipe with two removable end caps with "O" ring seals. The joints connecting the flow tubes to the bulkheads and optics blocks are "O" ring seals as is the pH housing and the electrical connector. The temperature probe and depth sensor use pipe thread seals.

This system is designed to withstand pressures to 150 psi; the limiting factor at this point is the pH probe. This unit has been tested in a hydrostatic pressure chamber for a duration of 4 hours at 150 psi.

#### 4.0 Shipboard Control Unit (Refer to Figure 3)

The Shipboard Control Unit (SCU) is used to decode the data from the towed instrument and provide a real time display. This unit

generates control functions and provides the power to the underwater unit.

As seen in Figure 3, the data controller receives serial data from the Underwater Instrumentation Package and provides a reconstructed 12 bit data word for each sensor. A 12 bit digital to analog (D/A) converter provides a DC output voltage for analog recording.

The output of the D/A converter is connected to six sample and hold buffer circuits controlled by the data controller. This provides continuous simultaneous display of all sensors. The sensor information is continuously displayed on a front panel digital display. Control switches generate a control word through the data controller which is transmitted via the data down link to change functions in the Underwater Instrumentation Package. The power for the instrument is generated by a 1.5A constant current supply.

#### 4.1 Controls

The control switches necessary for operating the SCU and the UIP are located on the front panel of this unit. The following is a functional description of each control:

Control Unit Power: Controls the power to the SCU only.

Sensor Power: Connects the 1.5A constant current power source to the instrument cable.

Alarm On/Off: Enables the alarm that indicates data error or wet sensor on.

Alarm Reset: Resets circuitry that triggers the alarm; if error signal is not present will turn alarm off.

Reset: General reset for all circuitry in the SCU.

Lamp Polarity SW: Not Used.

Lamp Polarity Indicator: Not Used

Lamp Start: This switch is actuated to turn the lamp on; the bottom half of the switch lights, indicating that the lamp HV Power Supply is energized. The top half of the switch lights when the lamp is energized and drawing current.

Auto Zero /Fixed Reference: Not used.

Initiate: Used to turn-off lamp High Voltage Power Supply after lamp is energized.

Constant Volts/Loop: This switch selects the mode of operation of the light source in the instrument. Top half of switch indicates constant volts, bottom, Loop Control.

Wet Sensor/Data Error: Indicates either a detection of moisture in the instrument or a loss of data from the instrument.

#### 4.2 Display/External Monitor

The display consists of six individual digital readouts: one for each sensor. All the displays are 3 1/2 digits; maximum value displayed is 1999. The temperature, depth, and pH displays readout in engineering units. The depth range is from 0.0 to 100.0 meters. The temperature range is from 0.0 to 30.0°C. The pH range is from 0.0 to 14.0. The absorption, fluorescence, and turbidity display voltage range is from -10.00 volts to +10.00 volts.

Located on the rear panel of the unit are BNC connectors for each sensor. These provide DC voltages for external recording. The voltage range for depth, temperature, and pH is 0 to +10.0 volts for full range of the sensor. The fluorescence, absorption, and turbidity will be the same value as displayed on the digital display: +10.0 volts. The fluorescence and absorption signals at this point will go to a more negative voltage with an increase in signal levels; i.e., -10.0 volts equals maximum signal levels. The turbidity will go in the positive direction for increase in signal; i.e., +10.0 volts equals maximum signal level.

#### 4.3 Circuit Description

##### 4.3.1 Demultiplexer (Refer to Drawing 5166-0331)

The Demultiplexer section consists of two circuit boards in the unit and is basically the same as the multiplexer circuitry in the UIP.

The demultiplexer is an interrupt driven microprocessor system. The serial data stream from the UIP is reassembled by the microprocessor into a 12 bit data word. This data word is converted to an analog voltage via the D/A converter. This conversion is done for each sensor; a control pulse is generated along with the conversion that latches the



DC voltage into sample and hold circuits for each sensor channel. The status word that is generated by the instrument is also decoded into control bits to drive the indicators. Switch functions are stored by this circuit and are transmitted to the UIP at the appropriate time, between data transmissions from the UIP.

The demultiplexer circuitry has six basic subsections: microprocessor, control decoding, universal asynchronous receiver transmitter (UART), status word control, switch control, and the D/A converter.

The microprocessor (U20) is the same as that used in the multiplexer except for a different program. The interrupt for this section is generated by the UART for data received. Each byte of data generates an interrupt. The data from the UART is taken by the microprocessor and routed to the appropriate outputs. A second interrupt is generated when a switch function is changed. At this time the microprocessor takes the data from the switch control and routes it to the UART which in turn transmits the data to the UIP via the data down link.

The control decoding consists of circuits U24, U25, U39, and U40. The microprocessor sends a control word to these circuits which in turn decode the word into control signals. U24 and U25 generate signals used within the demultiplexer, while U39, U30, and U40 decode the signals that control the sample and hold circuits, of which a maximum of 16 can be controlled.

The UART controls the transmitting and receiving of data. It receives serial data through the line receiver (U42) and converts the data to a parallel 8-bit word for use by the microprocessor. The reverse is true for transmitting data. Eight bit parallel data is taken in and converted to serial data and transmitted by the line driver (U36) to the instrument package.

The status word control receives its data as an 8-bit word from the microprocessor, latches the data in U21, and drives the indicator lamps with U22.

The switch control consists of U31, U34, U35, and U41. Switch conditions are latched by U34 and U35. U31 is used to interface this data to the microprocessor.

The D/A converter consists of U37, U38 and the D/A converter (U52). The purpose of U37 and U38 is to receive the data from the microprocessor in two separate data transfers: one 8-bit byte and one 4-bit byte. These circuits then present a composite 12 bit word to the D/A converter.

#### 4.3.2 Sample and Hold Circuit (Refer to Drawing 5166-0320)

The sample and hold circuit is a separate board (5166-0320) which contains 8 channels. One DC input from the D/A converter is common to all the channels. There are 8 control lines that are pulsed to latch the voltage into the appropriate channel. The sample and hold circuits are buffered by an additional operational amplifier to drive external recording equipment.

#### 4.3.3 Digital Display (Refer to Drawing 5166-0311)

This section consists of a display which has six 3 1/2 digit LED displays. The displays have a built-in latch which holds the data between updates. The other section is an A/D converter card (5166-0311) which contains DC scaling amplifiers, a 12-bit A/D Binary Coded Decimal (BCD) converter, and control circuitry.

The inputs to this circuit are the outputs of the sample and hold circuits. The input scaling amplifiers convert the DC voltages to a voltage range that can be converted and displayed as engineering units. The control circuitry and the A/D converter continuously sample the scaling amplifier, convert the voltage to 3 1/2 digit BCD data word, and latch the data into the appropriate display.

The operation of this circuit can be explained by referring to Drawing 5166-0311. The input scaling amplifiers (U1 through U3) are routed to the A/D converter (U6) by analog FET switches that are controlled by a shift register (U13) which also enables the strobe gates (U7 and U8). The position of the bit in the shift register determines the channel being converted. U33 determines the sample time. At the end of each conversion, the shift register is incremented. U14 through U16 latch the polarity information and the data for the most significant display digit.

The following procedure is used to adjust the display circuitry:

- (1) Remove U4 and U5.
- (2) Place a power supply across R33 and set to 199.85 mV; adjust R36 until depth display is switching from 199.8 to 199.9.
- (3) Apply 0.00 mV across R33 and adjust R37 for 0.0V.
- (4) Repeat steps (2) and (3) until required parameters are obtained.
- (5) Remove power supply from R33.
- (6) Replace U4, U5.

- (7) Apply 10V to the input of all six channels; adjust R14 for a 100.0 reading on depth, R16 for a reading of 10.0 on fluorescence, R18 for a reading of 30.0 on temperature, R20 for a reading of 10.0 on absorption, R22 for a reading of 14.0 of pH, and R24 for a reading of 10.0 on turbidity.

#### 4.4 Operational Procedure

Operation of the SCU and the UIP is straight forward. The following procedure should be used:

- (1) Turn power On to the SCU.
- (2) Initiate the RESET Switch. The displays will indicate meaningless data.
- (3) Turn Power ON to the UIP. The temperature, pH, and depth should indicate real data. The fluorescence, absorption, and turbidity will be meaningless. The Lamp ON indicator and High Voltage ON indicator should NOT be illuminated.
- (4) If the Constant Volts/Loop indicates constant volts, select loop.
- (5) Depress the Lamp START switch.  
The High Voltage ON indicator should be ON. The Constant Volts indicator should be ON.
- (6) When the Lamp ON indicator comes ON, depress the Initiate switch. The following should occur:  
High Voltage indicator OFF  
Constant Volts indicator OFF  
The Loop indicator ON  
Lamp indicator ON
- (7) If the Lamp fails to remain on, initiate RESET and repeat the sequence.
- (8) If the UIP is in the water or the flow tube is filled with water, the fluorescence, absorption, and turbidity readings should be close to zero volts.

#### 5. System Calibration

##### 5.1 Fluorescence and Absorption

The calibration of the fluorescence and absorption measurement is based on a background level produced by deionized water. The background level is then assumed to be interfering signals caused by coupling of the light source to the detector. This background is electrically suppressed in the conditioning circuitry. Standard samples of different concentrations of chemicals are then poured into the instrument and a voltage is recorded for that concentration.

#### 5.1.1 Standard Sample

A standard solution is prepared using commercial grade chemicals (Figure 11). The initial solution is a concentration of  $10^{-3}$  and is prepared as shown in Figure 12. These solutions are kept refrigerated until used. The standard solution is then diluted with deionized water to achieve the desired concentrations for calibration.

#### 5.1.2 Calibration Procedure:

- (1) Rinse the UIP flow tube with alcohol.
- (2) Flush several times with deionized water to remove the alcohol.
- (3) Fill with deionized water. Observe the reading on the fluorescence and absorption displays. If the readings are not close to zero volts, an adjustment of the zero suppression must be made. Step 4.
- (4) Adjustments are found on circuit board 5166-0211. The absorption adjustments are R32 (coarse) and R12 (vernier). The fluorescence adjustments are R33 (coarse) and R13 (vernier). Adjust the vernier controls to zero the display. If the vernier has no effect on the display, turn the vernier full counterclockwise and adjust the coarse to bring the display close to zero. Fine adjust with the vernier.
- (5) Starting with the lowest concentration of the calibration solution, fill the instrument and record the readings.
- (6) After the final reading, flush the instrument with deionized water and re-check the zero point.
- (7) Caution should be taken to avoid creating bubbles when filling the instrument with solutions - the bubbles will cause scattering in the measuring chamber resulting in false levels.

#### 5.1.3 Data

The calibration of the instrument to date has been done with anthracene. The anthracene calibration curve (Figure 13), shows a sensitivity of  $10^{-9}$  which is equivalent to the sensitivity desired. The oils measured (Figure 14) have a sensitivity of parts in  $10^{-7}$  which is two orders of magnitude less sensitive than previously measured (Figure 15).

#### 5.2 Turbidity

Solutions that are based on a standard Nephelometric Turbidity Unit (NTU) solution are used for the turbidity calibration. The original intent was to measure the loss of light and also the amount of scattered

Figure 11  
CHEMICAL SAMPLES

<u>Chemical</u>	<u>Supplier</u>	<u>Lot #</u>	
Anthracene	Eastman 480	B7H	Solid
AS-007-CDO (Crude)	Coast Guard R&D		
Benzene	Eastman 13012	D4C	Liquid
Chrysene	Eastman 4217	681-1N	Solid
Cumene	Eastman 1481	C7B	Liquid
Diesel oil	APL		
Ethylbenzene	Eastman 719	D8B	Liquid
GE-003-CME (Crude)	Coast Guard R&D		
Heating oil	APL		
Hydroquinone	Eastman 201	C8B	Solid
M-Xylene	Eastman 275	A8X	Liquid
Napthalene	Eastman 168	C4B	Solid
O-Cresol	Eastman P81	A5E	Liquid
P-Cresol	Eastman P449	B7E	Liquid
Phenol	Eastman 201	A8B	Solid
Phthatic Acid	Fisher A-256	731659	Solid
Quinoline	Eastman 218	A8B	Liquid
Styrene	Eastman 1465	B9A	Liquid
Toluene	Eastman 13037	E4A	Liquid
Turpentine	APL		

Figure 12

STANDARD  $10^{-3}$  SOLUTION PREPARATION

<u>Chemical</u>	<u>Mixture (<math>10^{-3}</math>)</u>
Anthracene	.1 gm $\rightarrow$ 100 ML Ethyl Alcohol
AS-007-CDO (Crude)	.1 gm $\rightarrow$ 100 ML Ethyl Alcohol
Benzene	.1 gm $\rightarrow$ 100 ML Deionized H <sub>2</sub> O
Chrysene	.01 gm $\rightarrow$ 100 ML Ethyl Alcohol = $10^{-4}$
Cumene	.1 gm $\rightarrow$ 100 ML Ethyl Alcohol
Diesel oil	.1 gm $\rightarrow$ 100 ML Ethyl Alcohol
Ethylbenzene	.1 gm $\rightarrow$ 100 ML Ethyl Alcohol
GE-003-CME (Crude)	.1 gm $\rightarrow$ 100 ML Ethyl Alcohol
Heating oil	.1 gm $\rightarrow$ 100 ML Ethyl Alcohol
Hydroquinone	.1 gm $\rightarrow$ 100 ML Deionized H <sub>2</sub> O
M-Xylene	.1 gm $\rightarrow$ 100 ML Ethyl Alcohol
Napthalene	.1 gm $\rightarrow$ 100 ML Ethyl Alcohol
O-Cresol	.1 gm $\rightarrow$ 100 ML Ethyl Alcohol
P-Cresol	.1 gm $\rightarrow$ 100 ML Ethyl Alcohol
Phenol	.1 gm $\rightarrow$ 100 ML Deionized H <sub>2</sub> O
Phthatic Acid	.1 gm $\rightarrow$ 100 ML Ethyl Alcohol
Quinoline	.1 gm $\rightarrow$ 100 ML Ethyl Alcohol
Styrene	.1 gm $\rightarrow$ 100 ML Ethyl Alcohol
Toluene	.1 gm $\rightarrow$ 100 ML Ethyl Alcohol
Turpentine	.1 gm $\rightarrow$ 100 ML Ethyl Alcohol

FIGURE 13:

CALIBRATION CURVE

ANTHRACENE

FLUORESCENCE

ABSORPTION




FIGURE 14:

CALIBRATION CURVE

CRUDE OIL

(AM-030-CTR)






Figure 15

## Sensitivity Comparison

Chemical	Baird Data		S/N = 2		APL Data		APL	
	Excitation $\lambda$ (NM)	BW2NM $\lambda$ (NM) Emission	Detection Limit (PPM)	S/N = 2 Detection Limit (PPM)	Detection Limit (PPM) Defionized H <sub>2</sub> O	Detection Limit (PPM) Seawater	Absorption Data	
							@253.7 NM Detection Limit (PPM) Defionized H <sub>2</sub> O	Detection Limit (PPM) Seawater
Anthracene	355	378	.001	.001	.001	.001	.01	.1
Benzene	250/265	279	2/4	2/4	1.0	1.0	1.0	6.0
Chrysene	270	383	.002	.001	.001	.001	.05	.1
Cumene	250	283	3.0	.1	.1	1.0	.1	.1
Ethylbenzene	260/250	283	1.5/3.1	1.0	1.0	2.0	10.0	4.0
Hydroquinone	290	326	.025	.01	.01		.05	.02
M-Xylene	270/260	285	1.4/2.0	1.0	1.0	1.0	.2	1.0
Napthalene	280	323	.02	.001	.001	.001	.05	.05
O-Cresol	280	293	.04	.006	.006	.05	.3	1.0
P-Cresol	280	299	.03	.006	.006	.01	.5	.5
Phenol	275/265	288	.007/.011	.01	.01	.01	.05	.05
Phthatic Acid	280/340	339	84/97	2.0	2.0	2.0	.5	.5
Quinoline	275	321	No Data	.1	.1		.05	
Styrene	270	306	.03	.001	.001	.001	.03	.01
Toluene	215/250	284	1.6/2.1	.3	.3	2.0	1.0	2.0
Turpentine	270/260	283	13/31	6.0	6.0	6.0	1.0	1.0
GE-003-CME	-	-	-	.005	.005	.005	.4	.1
Heating oil	-	-	-	.005	.005	.005	.05	.1
AS-007-CDO	-	-	-	.005	.005	.005	.1	.1
Diesel oil	-	-	-	.005	.005	.005	.05	.05

light. Due to lamp stability problems only the scattered light was measured. The turbidity calibration is based on scattered light produced by the standard NTU solutions.

#### 5.2.1 Standard Samples

The standard solution is based on a Formazin polymer used as the turbidity reference suspension. A stock turbidity suspension is the base solution and is prepared as follows:

Solution 1: Dissolve 1.00 g hydrazine sulfate in distilled water and dilute to 100 ml in a volumetric flask.

Solution 2: Dissolve 10.00 g hexamethylenetetramine in distilled water and dilute to 100 ml in a volumetric flask.

In a 100 ml volumetric flask, mix 5.0 ml solution 1 with 5.0 ml solution 2. Allow to stand 24 hours at  $15^{\circ}\text{C} \pm 3^{\circ}\text{C}$  then dilute to the 100 ml mark and mix. This solution is then equal to 400 NTU. Mix solution using the 400 solution and distilled water to produce 40, 4 and 0.4 NTU solutions. The stock solution is good for approximately a month, but the diluted solutions should be remixed every week.

This procedure is used by the Environmental Protection Agency to calibrate Nephelometers for measuring turbidity of drinking water.

#### 5.2.2 Calibration Procedure:

- (1) Rinse the UIP flow tube several times with water. Fill with distilled water.
- (2) The reading on the turbidity display should be approximately zero. If not zero, readjust zero point (Step 3).
- (3) If only the one detector is being used (scattering) - adjust R13 (Vernier) on card 5166-0141 for a zero reading. If the display does not change with R13, turn R13 counterclockwise and adjust R33 (coarse) for near zero reading, then readjust R13 for zero.

If both the scattering and absorption measurements are being used, then the above procedure must be used for both. The adjustments for absorption are R12 (vernier) and R32 (coarse) on the same board.

If both must be adjusted, the output of board 5166-0141 must be monitored when adjusting each (pin A absorption

and pin S scattering). When both are adjusted to zero the display should be zero.

(4) Starting with the 0.4 NTU solution, fill the UIP flow tube and record the display reading. Repeat for each solution.

(5) After the last solution, rinse the UIP flow tube and fill with distilled water to re-check zero point.

NOTE: Before any solutions are used for measurements, they should be well shaken and let stand until the air bubbles are gone. Care should be taken when filling the flow tube with solution; any air bubbles created will cause false readings.

#### 5.2.3 Data

This instrument was calibrated using the calibration procedure over a NTU range of 0.4 to 400. Figure 16 is this calibration curve.

#### 5.3 pH Probe

The pH probe is calibrated at three points: 4, 7, and 10. This gives a good indication of accuracy and linearity.

##### 5.3.1 Standard Samples

The solutions used were prepared using Metrepack P-Hydrion Buffers. The buffers are contained in premeasured capsules and are mixed with 100 ml of the distilled water. The accuracy of the solution is  $\pm 0.02$  pH units.

##### 5.3.2 Data

Figure 17 is the calibration curve.

#### 5.4 Temperature

The temperature probe was calibrated using a temperature controlled oil bath; the calibration was done at  $0^{\circ}\text{C}$ ,  $25^{\circ}\text{C}$  and  $30^{\circ}\text{C}$ .

##### 5.4.1 Standard Source

The source was a Guildline Model 9730 Constant Temperature Oil Bath, with a system accuracy of  $5\text{m}^{\circ}\text{C}$ .

##### 5.4.2 Data

Figure 18 is the calibration curve.

FIGURE 16:

CALIBRATION CURVE

TURBIDITY




FIGURE 17:

pH PROBE CALIBRATION





FIGURE 18:

TEMPERATURE PROBE CALIBRATION



## 5.5 Depth

The depth calibration was done using a standard pressure test source in 20 psi steps to a maximum of 145 psi which is equal to 100 meter depth.

### 5.5.1 Standard Source

The source used was a Chandler Engineering Co. Model 58-155 Precisions Pressure Standard with a system accuracy of 0.02%.

### 5.5.2 Data

Figure 19 is the calibration curve.

## 6.0 System Status

### 6.1 Sensitivity Comparison

The main objective was to develop an instrument with high sensitivity for the fluorescence and absorption detection. The turbidity sensor has not been specified for sensitivity. The required sensitivity for fluorescence was 1 part per billion. The absorption sensitivity was undefined. Previous laboratory tests using a laboratory set-up equivalent to the detection scheme used in this instrument produced results as shown in Figure 15.


The sensitivity measurement made at APL on the prototype instrument did not include the entire list of chemicals but concentrated on anthracene and crude oil. The sensitivity curve shown in Figure 13. for anthracene compares favorably with the previous data. The oil sensitivity was less, as shown in Figure 15. At this time the decrease in sensitivity is unexplainable. It could possibly be attributed to a high background level in the UIP due to coupling of light from the lamp to the fluorescence detector.

Further investigation is needed to examine the reduced sensitivity and determine the exact cause. One possible solution is to reduce light coupling from the light source to the detector by installing a lens to focus the light in the measuring chamber.

### 6.2 Lamp Stability

The lamp used is basically a very stable light source; but due to packaging requirements and available components, the lamp was not operated in its normal mode. The lamp is normally operated from an AC power source. Since the power supplies normally used were too large to package in the instrument, a DC power source was selected.

FIGURE 19:





The operation of the lamp using DC power is acceptable according to the manufacturer, but limitations exist. Migrating of the mercury to one electrode reduces the lifetime of the lamp. This also can cause a shift in the spectrum and reduced light output. The change in lamp performance has been noted in the instrument and causes drift resulting in unstable zero reference levels.

Further investigation is needed to determine the feasibility of designing an AC power source.

### 6.3 Conclusions

The towed fluorometer hardware developed by APL per the first year final report for the Coast Guard R & D Center (APL memorandum EEO-80-4) has met the specifications outlined by the Coast Guard R & D Center. As outlined in this report, areas exist for design improvement within the UIP. The system has undergone laboratory test at APL under the supervision of the Coast Guard sponsor.


The system has had an initial at-sea test aboard the Coast Guard Ship "Evergreen". During this test, the basic design areas were evaluated: towing configuration, sensor stability, and background levels. During this test, no attempt was made to determine the in-situ sensitivity and accuracy of the system.


The system has been delivered to the Coast Guard R & D Center for further evaluation.

## APPENDIX A

### Drawings - Underwater Instrumentation Package.

Mechanical Assembly	5166-0100
Wiring Diagram	5166-0101
Windows - Optics Block	5166-0115
pH Probe	5166-0116
Logarithmic Amplifier - Turbidity	5166-0141
Temperature/Depth Conditioning	5166-0151
Lamp Control	5166-0161
Auxiliary Electronics	5166-0171
Voltage Regulator Assembly #1	5166-0181
Voltage Regulator Assembly #2	5166-0191
Photomultiplier and High Voltage Power Supply Assembly	5166-0201
Logarithmic Amplifiers Fluorescence and Absorption	5166-0211
pH Probe Conditioning	5166-0231
Analog to Digital Converter	5154-0121
Multiplexer Control	5154-0141






# NOTES:






1. PROPOSED MATERIAL: AMERCIL;  
SUPERCIL 1, ULTRAVIOLET FINISH  
WINDOWS TO BE USED @ 2537Å  
AND LARGER WAVELENGTHS
2. PLATE GLASS SURFACE QUALITY

REVISIONS			DATE	BY	DESCRIPTION	CHG. BY	APPROVED & DATE
6	3/14/80	CLK			CHANGED MAT'L FROM COM-MERICAL GRADE UV QUARTZ TO 90% TRANSMISSION OF UV, 2600Å	CLK	3/14/80

THE JOHNS HOPKINS UNIVERSITY APPLIED PHYSICS LABORATORY 800 GEORGIA AVENUE SILVER SPRING, MARYLAND		DATE 1/17/80	
NAME C.J. KARDIAN		DATE 1/17/80	
DRAWN BY C.J. KARDIAN		CHECKED C.J. KARDIAN	
MATERIAL: SEE NOTE 1		FINISH SEE NOTE 2	
UNLESS OTHERWISE NOTED DIMENSIONS ARE IN INCHES DECIMAL TOL. ± 1/64 XX - ± .03 XXX - ± .010		SERIAL NO. 5166-0115	
QTY 1		SERIAL NO. 5166-0115	
NEXT ASSEMBLY		SERIAL NO. 5166-0115	
USAGE		SERIAL NO. 5166-0115	
CODE IDENT NO. 88898		SIZE B	
SCALE 2:1		DO NOT SCALE PRINT	
SHEET 1		UP 1	



FROM 1985 TO 1987

[illegible][illegible][illegible][illegible][illegible][illegible][illegible][illegible]

A hand-drawn graph on a grid background. The horizontal axis (x-axis) is labeled 'No. of leaves' and has tick marks from 0 to 10. The vertical axis (y-axis) is labeled 'No. of flowers' and has tick marks from 0 to 10. Five data points are plotted at (2, 1), (4, 2), (6, 3), (8, 4), and (10, 5). These points are connected by a straight line that starts at the origin (0, 0) and extends upwards to the right.

The image shows a hand-drawn schematic of a 2D lattice and its energy band structure.

**Left Diagram (Lattice):** A rectangular box labeled "2D Lattice" contains a grid of dots representing atoms. The grid is 4 dots wide and 3 dots high. The top-left dot is labeled "A", the top-middle dot is labeled "L", and the top-right dot is labeled "B". To the right of the grid, the text "MnO<sub>2</sub> 2x2" and "2x2" are written.

**Right Diagram (Energy Band):** A graph showing energy levels. The vertical axis is labeled "Energy" and the horizontal axis is labeled "Momentum". A horizontal line represents the Fermi level, labeled "Fermi Level". Several energy levels are marked with dots and labels:
 

- At the top, a dot is labeled "A 1".
- Below it, a dot is labeled "A 2".
- Below that, a dot is labeled "B 1".
- Below that, a dot is labeled "B 2".
- Below that, a dot is labeled "L 1".
- Below that, a dot is labeled "L 2".
- Below that, a dot is labeled "L 3".
- Below that, a dot is labeled "L 4".
- Below that, a dot is labeled "L 5".
- Below that, a dot is labeled "L 6".
- Below that, a dot is labeled "L 7".
- Below that, a dot is labeled "L 8".
- Below that, a dot is labeled "L 9".
- Below that, a dot is labeled "L 10".
- Below that, a dot is labeled "L 11".
- Below that, a dot is labeled "L 12".
- Below that, a dot is labeled "L 13".
- Below that, a dot is labeled "L 14".
- Below that, a dot is labeled "L 15".
- Below that, a dot is labeled "L 16".
- Below that, a dot is labeled "L 17".
- Below that, a dot is labeled "L 18".
- Below that, a dot is labeled "L 19".
- Below that, a dot is labeled "L 20".
- Below that, a dot is labeled "L 21".
- Below that, a dot is labeled "L 22".
- Below that, a dot is labeled "L 23".
- Below that, a dot is labeled "L 24".
- Below that, a dot is labeled "L 25".
- Below that, a dot is labeled "L 26".
- Below that, a dot is labeled "L 27".
- Below that, a dot is labeled "L 28".
- Below that, a dot is labeled "L 29".
- Below that, a dot is labeled "L 30".
- Below that, a dot is labeled "L 31".
- Below that, a dot is labeled "L 32".
- Below that, a dot is labeled "L 33".
- Below that, a dot is labeled "L 34".
- Below that, a dot is labeled "L 35".
- Below that, a dot is labeled "L 36".
- Below that, a dot is labeled "L 37".
- Below that, a dot is labeled "L 38".
- Below that, a dot is labeled "L 39".
- Below that, a dot is labeled "L 40".
- Below that, a dot is labeled "L 41".
- Below that, a dot is labeled "L 42".
- Below that, a dot is labeled "L 43".
- Below that, a dot is labeled "L 44".
- Below that, a dot is labeled "L 45".
- Below that, a dot is labeled "L 46".
- Below that, a dot is labeled "L 47".
- Below that, a dot is labeled "L 48".
- Below that, a dot is labeled "L 49".
- Below that, a dot is labeled "L 50".
- Below that, a dot is labeled "L 51".
- Below that, a dot is labeled "L 52".
- Below that, a dot is labeled "L 53".
- Below that, a dot is labeled "L 54".
- Below that, a dot is labeled "L 55".
- Below that, a dot is labeled "L 56".
- Below that, a dot is labeled "L 57".
- Below that, a dot is labeled "L 58".
- Below that, a dot is labeled "L 59".
- Below that, a dot is labeled "L 60".
- Below that, a dot is labeled "L 61".
- Below that, a dot is labeled "L 62".
- Below that, a dot is labeled "L 63".
- Below that, a dot is labeled "L 64".
- Below that, a dot is labeled "L 65".
- Below that, a dot is labeled "L 66".
- Below that, a dot is labeled "L 67".
- Below that, a dot is labeled "L 68".
- Below that, a dot is labeled "L 69".
- Below that, a dot is labeled "L 70".
- Below that, a dot is labeled "L 71".
- Below that, a dot is labeled "L 72".
- Below that, a dot is labeled "L 73".
- Below that, a dot is labeled "L 74".
- Below that, a dot is labeled "L 75".
- Below that, a dot is labeled "L 76".
- Below that, a dot is labeled "L 77".
- Below that, a dot is labeled "L 78".
- Below that, a dot is labeled "L 79".
- Below that, a dot is labeled "L 80".
- Below that, a dot is labeled "L 81".
- Below that, a dot is labeled "L 82".
- Below that, a dot is labeled "L 83".
- Below that, a dot is labeled "L 84".
- Below that, a dot is labeled "L 85".
- Below that, a dot is labeled "L 86".
- Below that, a dot is labeled "L 87".
- Below that, a dot is labeled "L 88".
- Below that, a dot is labeled "L 89".
- Below that, a dot is labeled "L 90".
- Below that, a dot is labeled "L 91".
- Below that, a dot is labeled "L 92".
- Below that, a dot is labeled "L 93".
- Below that, a dot is labeled "L 94".
- Below that, a dot is labeled "L 95".
- Below that, a dot is labeled "L 96".
- Below that, a dot is labeled "L 97".
- Below that, a dot is labeled "L 98".
- Below that, a dot is labeled "L 99".
- Below that, a dot is labeled "L 100".


34125

Case	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100
1	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100

[illegible]

1.  $\frac{1}{2}$

12




1716	PART NUMBER	1717	1718	1719	1720	1721	1722	1723	1724	1725	1726	1727	1728	1729	1730	1731	1732	1733	1734	1735	1736	1737	1738	1739	1740	1741	1742	1743	1744	1745	1746	1747	1748	1749	1750	1751	1752	1753	1754	1755	1756	1757	1758	1759	1760	1761	1762	1763	1764	1765	1766	1767	1768	1769	1770	1771	1772	1773	1774	1775	1776	1777	1778	1779	1780	1781	1782	1783	1784	1785	1786	1787	1788	1789	1790	1791	1792	1793	1794	1795	1796	1797	1798	1799	1800	1801	1802	1803	1804	1805	1806	1807	1808	1809	1810	1811	1812	1813	1814	1815	1816	1817	1818	1819	1820	1821	1822	1823	1824	1825	1826	1827	1828	1829	1830	1831	1832	1833	1834	1835	1836	1837	1838	1839	1840	1841	1842	1843	1844	1845	1846	1847	1848	1849	1850	1851	1852	1853	1854	1855	1856	1857	1858	1859	1860	1861	1862	1863	1864	1865	1866	1867	1868	1869	1870	1871	1872	1873	1874	1875	1876	1877	1878	1879	1880	1881	1882	1883	1884	1885	1886	1887	1888	1889	1890	1891	1892	1893	1894	1895	1896	1897	1898	1899	1900	1901	1902	1903	1904	1905	1906	1907	1908	1909	1910	1911	1912	1913	1914	1915	1916	1917	1918	1919	1920	1921	1922	1923	1924	1925	1926	1927	1928	1929	1930	1931	1932	1933	1934	1935	1936	1937	1938	1939	1940	1941	1942	1943	1944	1945	1946	1947	1948	1949	1950	1951	1952	1953	1954	1955	1956	1957	1958	1959	1960	1961	1962	1963	1964	1965	1966	1967	1968	1969	1970	1971	1972	1973	1974	1975	1976	1977	1978	1979	1980	1981	1982	1983	1984	1985	1986	1987	1988	1989	1990	1991	1992	1993	1994	1995	1996	1997	1998	1999	2000	2001	2002	2003	2004	2005	2006	2007	2008	2009	2010	2011	2012	2013	2014	2015	2016	2017	2018	2019	2020	2021	2022	2023	2024	2025	2026	2027	2028	2029	2030	2031	2032	2033	2034	2035	2036	2037	2038	2039	2040	2041	2042	2043	2044	2045	2046	2047	2048	2049	2050	2051	2052	2053	2054	2055	2056	2057	2058	2059	2060	2061	2062	2063	2064	2065	2066	2067	2068	2069	2070	2071	2072	2073	2074	2075	2076	2077	2078	2079	2080	2081	2082	2083	2084	2085	2086	2087	2088	2089	2090	2091	2092	2093	2094	2095	2096	2097	2098	2099	2100	2101	2102	2103	2104	2105	2106	2107	2108	2109	2110	2111	2112	2113	2114	2115	2116	2117	2118	2119	2120	2121	2122	2123
------	-------------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

1716	PART NUMBER	1717	1718	1719	1720	1721	1722	1723	1724	1725	1726	1727	1728	1729	1730	1731	1732	1733	1734	1735	1736	1737	1738	1739	1740	1741	1742	1743	1744	1745	1746	1747	1748	1749	1750	1751	1752	1753	1754	1755	1756	1757	1758	1759	1760	1761	1762	1763	1764	1765	1766	1767	1768	1769	1770	1771	1772	1773	1774	1775	1776	1777	1778	1779	1780	1781	1782	1783	1784	1785	1786	1787	1788	1789	1790	1791	1792	1793	1794	1795	1796	1797	1798	1799	1800	1801	1802	1803	1804	1805	1806	1807	1808	1809	1810	1811	1812	1813	1814	1815	1816	1817	1818	1819	1820	1821	1822	1823	1824	1825	1826	1827	1828	1829	1830	1831	1832	1833	1834	1835	1836	1837	1838	1839	1840	1841	1842	1843	1844	1845	1846	1847	1848	1849	1850	1851	1852	1853	1854	1855	1856	1857	1858	1859	1860	1861	1862	1863	1864	1865	1866	1867	1868	1869	1870	1871	1872	1873	1874	1875	1876	1877	1878	1879	1880	1881	1882	1883	1884	1885	1886	1887	1888	1889	1890	1891	1892	1893	1894	1895	1896	1897	1898	1899	1900	1901	1902	1903	1904	1905	1906	1907	1908	1909	1910	1911	1912	1913	1914	1915	1916	1917	1918	1919	1920	1921	1922	1923	1924	1925	1926	1927	1928	1929	1930	1931	1932	1933	1934	1935	1936	1937	1938	1939	1940	1941	1942	1943	1944	1945	1946	1947	1948	1949	1950	1951	1952	1953	1954	1955	1956	1957	1958	1959	1960	1961	1962	1963	1964	1965	1966	1967	1968	1969	1970	1971	1972	1973	1974	1975	1976	1977	1978	1979	1980	1981	1982	1983	1984	1985	1986	1987	1988	1989	1990	1991	1992	1993	1994	1995	1996	1997	1998	1999	2000	2001	2002	2003	2004	2005	2006	2007	2008	2009	2010	2011	2012	2013	2014	2015	2016	2017	2018	2019	2020	2021	2022	2023	2024	2025	2026	2027	2028	2029	2030	2031	2032	2033	2034	2035	2036	2037	2038	2039	2040	2041	2042	2043	2044	2045	2046	2047	2048	2049	2050	2051	2052	2053	2054	2055	2056	2057	2058	2059	2060	2061	2062	2063	2064	2065	2066	2067	2068	2069	2070	2071	2072	2073	2074	2075	2076	2077	2078	2079	2080	2081	2082	2083	2084	2085	2086	2087	2088	2089	2090	2091	2092	2093	2094	2095	2096	2097	2098	2099	2100	2101	2102	2103	2104	2105	2106	2107	2108	2109	2110	2111	2112	2113	2114	2115	2116	2117	2118	2119	2120	2121	2122	2123
------	-------------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

1716	PART NUMBER	1717	1718	1719	1720	1721	1722	1723	1724	1725	1726	1727	1728	1729	1730	1731	1732	1733	1734	1735	1736	1737	1738	1739	1740	1741	1742	1743	1744	1745	1746	1747	1748	1749	1750	1751	1752	1753	1754	1755	1756	1757	1758	1759	1760	1761	1762	1763	1764	1765	1766	1767	1768	1769	1770	1771	1772	1773	1774	1775	1776	1777	1778	1779	1780	1781	1782	1783	1784	1785	1786	1787	1788	1789	1790	1791	1792	1793	1794	1795	1796	1797	1798	1799	1800	1801	1802	1803	1804	1805	1806	1807	1808	1809	1810	1811	1812	1813	1814	1815	1816	1817	1818	1819	1820	1821	1822	1823	1824	1825	1826	1827	1828	1829	1830	1831	1832	1833	1834	1835	1836	1837	1838	1839	1840	1841	1842	1843	1844	1845	1846	1847	1848	1849	1850	1851	1852	1853	1854	1855	1856	1857	1858	1859	1860	1861	1862	1863	1864	1865	1866	1867	1868	1869	1870	1871	1872	1873	1874	1875	1876	1877	1878	1879	1880	1881	1882	1883	1884	1885	1886	1887	1888	1889	1890	1891	1892	1893	1894	1895	1896	1897	1898	1899	1900	1901	1902	1903	1904	1905	1906	1907	1908	1909	1910	1911	1912	1913	1914	1915	1916	1917	1918	1919	1920	1921	1922	1923	1924	1925	1926	1927	1928	1929	1930	1931	1932	1933	1934	1935	1936	1937	1938	1939	1940	1941	1942	1943	1944	1945	1946	1947	1948	1949	1950	1951	1952	1953	1954	1955	1956	1957	1958	1959	1960	1961	1962	1963	1964	1965	1966	1967	1968	1969	1970	1971	1972	1973	1974	1975	1976	1977	1978	1979	1980	1981	1982	1983	1984	1985	1986	1987	1988	1989	1990	1991	1992	1993	1994	1995	1996	1997	1998	1999	2000	2001	2002	2003	2004	2005	2006	2007	2008	2009	2010	2011	2012	2013	2014	2015	2016	2017	2018	2019	2020	2021	2022	2023	2024	2025	2026	2027	2028	2029	2030	2031	2032	2033	2034	2035	2036	2037	2038	2039	2040	2041	2042	2043	2044	2045	2046	2047	2048	2049	2050	2051	2052	2053	2054	2055	2056	2057	2058	2059	2060	2061	2062	2063	2064	2065	2066	2067	2068	2069	2070	2071	2072	2073	2074	2075	2076	2077	2078	2079	2080	2081	2082	2083	2084	2085	2086	2087	2088	2089	2090	2091	2092	2093	2094	2095	2096	2097	2098	2099	2100	2101	2102	2103	2104	2105	2106	2107	2108	2109	2110	2111	2112	2113	2114	2115	2116	2117	2118	2119	2120	2121	2122	2123
------	-------------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------

1716	PART NUMBER	1717	1718	1719	1720	1721	1722	1723	1724	1725	1726	1727	1728	1729	1730	1731	1732	1733	1734	1735	1736	1737	1738	1739	1740	1741	1742	1743	1744	1745	1746	1747	1748	1749	1750	1751	1752	1753	1754	1755	1756	1757	1758	1759	1760	1761	1762	1763	1764	1765	1766	1767	1768	1769	1770	1771	1772	1773	1774	1775	1776	1777	1778	1779	1780	1781	1782	1783	1784	1785	1786	1787	1788	1789	1790	1791	1792	1793	1794	1795	1796	1797	1798	1799	1800	1801	1802	1803	1804	1805	1806	1807	1808	1809	1810	1811	1812	1813	1814	1815	1816	1817	1818	1819	1820	1821	1822	1823	1824	1825	1826	1827	1828	1829	1830	1831	1832	1833	1834	1835	1836	1837	1838	1839	1840	1841	1842	1843	1844	1845	1846	1847	1848	1849	1850	1851	1852	1853	1854	1855	1856	1857	1858	1859	18
------	-------------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	----

USE 01162870




# NOTES


1. BROADLEY-JAMES CORPORATION  
1714 SOUTH LYON STREET  
SANATA ANA, CALIFORNIA 92705
2. PH PROBE WITH REFERENCE ELECTRODE  
AND MEASURING ELECTRODE POTTED  
INTO A PVC HOUSING, WITH  
3/4" N.P.T. FITTINGS, 1" OUTSIDE  
DIAMETER X 3.0" OVERALL LENGTH.
3. PH RANGE 0-14  
TEMPERATURE RANGE 5° TO 80°C  
PRESSURE RANGE 150 PSI  
REFERENCE TO BE GEL-FILLED AG-AG CL


ITEM NO		PART NUMBER	CIRCUIT SYMBOL	PART NAME OR DESCRIPTION	SPECIFICATION	MFG CODE
QTY						
MATERIAL		LIST OF MATERIAL				
FINISH		NAME	DATE	THE JOHNS HOPKINS UNIVERSITY APPLIED PHYSICS LABORATORY 8341 SECOND AVE. BALTIMORE, MARYLAND		
		QTY	DATE	P.H. PROBE		
		HAZARDOUS CHEMICAL FLUOROMETER				
		CODE IDENT NO	REV	5166-0116		
		88898	C	a		
UNLESS OTHERWISE NOTED, DIMENSIONS ARE IN INCHES						
DECIMAL TOL						
FRACTIONS						
XX - X 03						
PART NUMBER	5166-0116	QTY	1	SER	NA	NO
NEXT ASSEMBLY	5166-0100	QTY	1	SER	NA	NO


5166-0116

[illegible]





[illegible]




ITEM NO	QTY	PART NUMBER	CIRCUIT SYMBOL	PART NAME OR DESCRIPTION	SPECIFICATION	MFG CODE
1	1	LM317		VOLTAGE REGULATOR		
2	1	470Ω		RESISTOR		
3	1	5KΩ		POTENTIOMETER		
4	1	240Ω		RESISTOR		
5	1	6.1K		POTENTIOMETER		
6	1	270Ω		RESISTOR		
7	1	2K		POTENTIOMETER		
8	1	1.5μF		TANTALUM CAPACITOR		
9	1	1μF		TANTALUM CAPACITOR		

ITEM NO	QTY	PART NUMBER	CIRCUIT SYMBOL	PART NAME OR DESCRIPTION	SPECIFICATION	MFG CODE
1	1	LM317		VOLTAGE REGULATOR		
2	1	470Ω		RESISTOR		
3	1	5KΩ		POTENTIOMETER		
4	1	240Ω		RESISTOR		
5	1	6.1K		POTENTIOMETER		
6	1	270Ω		RESISTOR		
7	1	2K		POTENTIOMETER		
8	1	1.5μF		TANTALUM CAPACITOR		
9	1	1μF		TANTALUM CAPACITOR		


ITEM NO	QTY	PART NUMBER	CIRCUIT SYMBOL	PART NAME OR DESCRIPTION	SPECIFICATION	MFG CODE
1	1	LM317		VOLTAGE REGULATOR		
2	1	470Ω		RESISTOR		
3	1	5KΩ		POTENTIOMETER		
4	1	240Ω		RESISTOR		
5	1	6.1K		POTENTIOMETER		
6	1	270Ω		RESISTOR		
7	1	2K		POTENTIOMETER		
8	1	1.5μF		TANTALUM CAPACITOR		
9	1	1μF		TANTALUM CAPACITOR		


ITEM NO	QTY	PART NUMBER	CIRCUIT SYMBOL	PART NAME OR DESCRIPTION	SPECIFICATION	MFG CODE
1	1	LM317		VOLTAGE REGULATOR		
2	1	470Ω		RESISTOR		
3	1	5KΩ		POTENTIOMETER		
4	1	240Ω		RESISTOR		
5	1	6.1K		POTENTIOMETER		
6	1	270Ω		RESISTOR		
7	1	2K		POTENTIOMETER		
8	1	1.5μF		TANTALUM CAPACITOR		
9	1	1μF		TANTALUM CAPACITOR		



QTY	ITEM NO	PART NUMBER	CIRCUIT SYMBOL	PART NAME OR DESCRIPTION	SPECIFICATION	MFG CODE
<div style="display: flex; justify-content: space-between;"> <div> <p>DATE: 12/11/81</p> <p>BY: S. JUSTICE</p> <p>REVISION: 1-1, 1-2, 1-3</p> </div> <div> <p>THE JOHNS HOPKINS UNIVERSITY</p> <p>APPLIED PHYSICS LABORATORY</p> <p>4000 GAITHERS RD</p> <p>BALTIMORE, MD 21218</p> </div> </div>						
<p>SCHEMATIC</p> <p>VOLTAGE REGULATOR ASSEMBLY #2</p> <p>HAZARDOUS CHEMICAL FLUOROMETER</p>						
88898		C	5166-0191	A		

UNLESS OTHERWISE NOTED DIMENSIONS ARE IN INCHES			
RE - 0.03	1/64		
FINISH			
MATERIAL			
ITEM NO			
PART NUMBER			
NEXT ASSEMBLY			
QTY			
SER			
NO			
REF			
5166-0191	5166-0190		
PART NUMBER			
USAGE			


[illegible]




NOTES:

1. UNLESS OTHERWISE SPECIFIED: ALL RES.'S ARE 1/10W, 1%. 2. E2 & E3 PROVIDE VOLTAGE TO R32 (E4 & E5) (R33 (E4 & E7))
3. TAILOR RESISTORS ASSOCIATED WITH U5 ARE ADJUSTED TO DESIRED INPUT VOLTAGES.

[illegible]



100




**NOTE:**

1. COMPONENT C4 SUPPLIED WITH UI

148 150 152	PART NUMBER	149 151 153	QUANTITY 1 1 1	UNIT	154 156 158	PART NAME OR DESCRIPTION	155 157 159	SPECIFICATIONS	160 162 164	QTY REQD
<p>APPLIED PHYSICS LABORATORY          161          163          165          SCHEMATIC          A/D CONVERTER          166          167          168          169          170          171          172          173          174          175          176          177          178          179          180          181          182          183          184          185          186          187          188          189          190          191          192          193          194          195          196          197          198          199          200          201          202          203          204          205          206          207          208          209          210          211          212          213          214          215          216          217          218          219          220          221          222          223          224          225          226          227          228          229          230          231          232          233          234          235          236          237          238          239          240          241          242          243          244          245          246          247          248          249          250          251          252          253          254          255          256          257          258          259          260          261          262          263          264          265          266          267          268          269          270          271          272          273          274          275          276          277          278          279          280          281          282          283          284          285          286          287          288          289          290          291          292          293          294          295          296          297          298          299          300          301          302          303          304          305          306          307          308          309          310          311          312          313          314          315          316          317          318          319          320          321          322          323          324          325          326          327          328          329          330          331          332          333          334          335          336          337          338          339          340          341          342          343          344          345          346          347          348          349          350          351          352          353          354          355          356          357          358          359          360          361          362          363          364          365          366          367          368          369          370          371          372          373          374          375          376          377          378          379          380          381          382          383          384          385          386          387          388          389          390          391          392          393          394          395          396          397          398          399          400          401          402          403          404          405          406          407          408          409          410          411          412          413          414          415          416          417          418          419          420          421          422          423          424          425          426          427          428          429          430          431          432          433          434          435          436          437          438          439          440          441          442          443          444          445          446          447          448          449          450          451          452          453          454          455          456          457          458          459          460          461          462          463          464          465          466          467          468          469          470          471          472          473          474          475          476          477          478          479          480          481          482          483          484          485          486          487          488          489          490          491          492          493          494          495          496          497          498          499          500          501          502          503          504          505          506          507          508          509          510          511          512          513          514          515          516          517          518          519          520          521          522          523          524          525          526          527          528          529          530          531          532          533          534          535          536          537          538          539          540          541          542          543          544          545          546          547          548          549          550          551          552          553          554          555          556          557          558          559          560          561          562          563          564          565          566          567          568          569          570          571          572          573          574          575          576          577          578          579          580          581          582          583          584          585          586          587          588          589          590          591          592          593          594          595          596          597          598          599          600          601          602          603          604          605          606          607          608          609          610          611          612          613          614          615          616          617          618          619          620          621          622          623          624          625          626          627          628          629          630          631          632          633          634          635          636          637          638          639          640          641          642          643          644          645          646          647          648  </p>										

85-4-1021-114-0120  
FBI - WASH DC  
JAN 11 1964







APPENDIX B


Drawings - Shipboard Control Unit.

Control Unit Wiring Diagram	5166-0301
Display Control Board	5166-0311
Sample and Hold Circuits	5166-0321
Demultiplexer Board 1	5166-0331
Demultiplexer Board 2	5166-0341






5166-0311-2



PART NUMBER		PART NAME OR DESCRIPTION		EXPLANATION	
88898	D	5166-0311	SCHEMATIC		
APPLIED PHYSICS CORPORATION					
842711 1st St. Northampton, MA 01060					
88898 D 5166-0311					

FORM 4110-000



DATE	TIME	TEST NO.	PAGE NUMBER	TEST NUMBER	TEST NAME OR DESCRIPTION	SPECIFICATION	DATE	TIME


APR 10 1966  
 THE UNITED STATES LABORATORY  
 1000 14th Street, N.W.  
 WASHINGTON, D.C. 20004

NOTE: DIAGRAM  
 SHOWS A BOLT OF MIX  
 CONTAINING THE MAX AL FLUOROCOME

88890 D 1166-0221

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	-----






COMPONENTS

REF. NO.	QTY.	DESCRIPTION	UNIT PRICE	TOTAL PRICE
1	1	7407	0.10	0.10
2	1	7407	0.10	0.10
3	1	7407	0.10	0.10
4	1	7407	0.10	0.10
5	1	7407	0.10	0.10
6	1	7407	0.10	0.10
7	1	7407	0.10	0.10
8	1	7407	0.10	0.10
9	1	7407	0.10	0.10
10	1	7407	0.10	0.10
11	1	7407	0.10	0.10
12	1	7407	0.10	0.10
13	1	7407	0.10	0.10
14	1	7407	0.10	0.10
15	1	7407	0.10	0.10
16	1	7407	0.10	0.10
17	1	7407	0.10	0.10
18	1	7407	0.10	0.10
19	1	7407	0.10	0.10
20	1	7407	0.10	0.10
21	1	7407	0.10	0.10
22	1	7407	0.10	0.10
23	1	7407	0.10	0.10
24	1	7407	0.10	0.10
25	1	7407	0.10	0.10
26	1	7407	0.10	0.10
27	1	7407	0.10	0.10
28	1	7407	0.10	0.10
29	1	7407	0.10	0.10
30	1	7407	0.10	0.10
31	1	7407	0.10	0.10
32	1	7407	0.10	0.10
33	1	7407	0.10	0.10
34	1	7407	0.10	0.10
35	1	7407	0.10	0.10
36	1	7407	0.10	0.10
37	1	7407	0.10	0.10
38	1	7407	0.10	0.10
39	1	7407	0.10	0.10
40	1	7407	0.10	0.10
41	1	7407	0.10	0.10
42	1	7407	0.10	0.10
43	1	7407	0.10	0.10
44	1	7407	0.10	0.10
45	1	7407	0.10	0.10
46	1	7407	0.10	0.10
47	1	7407	0.10	0.10
48	1	7407	0.10	0.10
49	1	7407	0.10	0.10
50	1	7407	0.10	0.10
51	1	7407	0.10	0.10
52	1	7407	0.10	0.10
53	1	7407	0.10	0.10
54	1	7407	0.10	0.10
55	1	7407	0.10	0.10
56	1	7407	0.10	0.10
57	1	7407	0.10	0.10
58	1	7407	0.10	0.10
59	1	7407	0.10	0.10
60	1	7407	0.10	0.10
61	1	7407	0.10	0.10
62	1	7407	0.10	0.10
63	1	7407	0.10	0.10
64	1	7407	0.10	0.10
65	1	7407	0.10	0.10
66	1	7407	0.10	0.10
67	1	7407	0.10	0.10
68	1	7407	0.10	0.10
69	1	7407	0.10	0.10
70	1	7407	0.10	0.10
71	1	7407	0.10	0.10
72	1	7407	0.10	0.10
73	1	7407	0.10	0.10
74	1	7407	0.10	0.10
75	1	7407	0.10	0.10
76	1	7407	0.10	0.10
77	1	7407	0.10	0.10
78	1	7407	0.10	0.10
79	1	7407	0.10	0.10
80	1	7407	0.10	0.10
81	1	7407	0.10	0.10
82	1	7407	0.10	0.10
83	1	7407	0.10	0.10
84	1	7407	0.10	0.10
85	1	7407	0.10	0.10
86	1	7407	0.10	0.10
87	1	7407	0.10	0.10
88	1	7407	0.10	0.10
89	1	7407	0.10	0.10
90	1	7407	0.10	0.10
91	1	7407	0.10	0.10
92	1	7407	0.10	0.10
93	1	7407	0.10	0.10
94	1	7407	0.10	0.10
95	1	7407	0.10	0.10
96	1	7407	0.10	0.10
97	1	7407	0.10	0.10
98	1	7407	0.10	0.10
99	1	7407	0.10	0.10
100	1	7407	0.10	0.10

APPLIED PHYSICS LABORATORY  
 DEPT. OF PHYSICS  
 UNIVERSITY OF CALIFORNIA  
 BERKELEY, CALIF. 94720  
 38896 D






ITEM	QTY	PART NUMBER	DESCRIPTION	DATE	BY
1	1	741	OP-AMP		
2	1	100K	RES		
3	1	0.01UF	CAP		
4	1	12VDC	SUPPLY		

SPECIFICATION	
MULTIPLIER BD. 2	
CONTROL UNIT	
HARCO CHEMICAL FLUOROMETER	
88898	5166-03-11

REVISIONS	
1	INITIALS
2	DATE
3	BY
4	DATE
5	BY

[illegible]

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	-----

END

FILMED

7-83

DTIC